

# Installation instructions for 550 side protection net

Parts list.

Side guard, L\*1

Side guard, R\*1



First, determine the installation position of the side guard. Then loosen the specific bolts on the vehicle. Place the corresponding parts of the side guard in the designated position, and then tighten the bolts to secure the side guard.



Fasten the two straps behind the side guardrail onto the vehicle.





Insert the pins in front of the side guardrail into the installation plate on the vehicle.



Fasten the buckle in front of the side guard to the vehicle. The installation order on both sides should be consistent.



Note:

To retrofit a net door on a unit with half doors, a **passenger handrail must be purchased and installed**, as the net door mounts directly onto these handrails. From a **safety standpoint**, this is also necessary — once the half doors are removed, there would otherwise be no handrail for the passenger.

Please **request for the VIN** to differentiate the build year, as the handrails for 2023 and 2024 are different.